



Bollard Assembly Guide

All Bollard Shapes and Sizes



Step 1: Take out your bollard sign and place it on a flat surface. The print should be facing upwards.



Step 2: Carefully fold each crease on the printed side first following the crease lines. Use the side of your palm to help you crease in the correct spot.



Step 3: Pre-creasing it will help hold its shape once it has been assembled.



Step 4: Flip your bollard sign over. The print should now be facing downwards.



Step 5: Fold each crease again on the back side following the crease lines. Use the side of your palm to help you crease in the correct spot.



Step 6: Fold your bollard sign in the correct shape.



Bollard Assembly Guide

All Bollard Shapes and Sizes



Step 7: Insert the outer tabs first using the self-locking system to hold the shape in place.



Step 8: The bigger tab slots inside the bigger hole, and the smaller tab slots inside the smaller hole.



Step 9: Insert the inner tabs using the self-locking system in the same manner as Step 7&8.



Step 10: You should now have an awesome looking bollard sign!